

## DOORHAN REMOTE PROGRAMMING

### A. To add a remote control

1. Press and hold the «R» on the motor unit in garage, until «00» appears on the display. Release the button.
2. Press any button of new remote you like to use twice.
3. Repeat above operations for other remote controls (maximum quantity — 20 pcs.).
4. All the remote controls will be added sequentially into the control block.
5. When the maximum quantity of remote controls is exceeded; three long beeps will sound.

### B. If your existing remote still work , you can program for Doorhan remote controller remotely

1. To press and hold the button «2» of the programmed remote control.
2. Without releasing the pressed button «2», to press and hold the button «1» of the remote control.
3. Release the buttons pressed.
4. Press the remote control button already set up.
5. On the new remote control, select a button with the help of which you will control the operator's work, and press it twice. A beep will sound.